

POWERAIL

Specifications



POWERRAIL

Specifications 1/2

Output

- 24 Outputs (**Positive and negative**) - configurable 1-16A,
- Current sensor - overrange current protection,
- Thermal protection,
- Dimmable light

Input

- 8 Inputs analog or digital,
- Sensitivity 100mV,
- Pull up,
- Analog 0-30V for tank sensor,
- Timed and damped,
- Dedicated power supply for sensor

Voltmeter

- 3 voltmeters,
- Input -30V to +30V,
- Auxiliary battery monitoring

Circuit isolation (hull)

- Positive and negative monitor : -16mA to +16mA,
- Automatic diagnostic,

Power

- 100 A max (1200 W)

Supply

- DC 10V to 30V,
- Connector bolt M8 stainless steel,
- internally protected MegaFuse 100A,
- Consumption 40mA

Communication

- CAN J1939 (Charger, Battery Lithium, ...)
- LIN (BMS, Sensors, Heating, ...)



POWERRAIL

Specifications 2/2

Environment

- Nominal -41°F + 113°F,
- IP61,
- MIL-STD810

Dimension

- 300 mm x 140 mm x 50 mm

Weight

- 1.4kg

Configuration


- Downloaded and stored automatically on the Sailsense HUB



POWERAIL


How does it work ?





Command via the HUB :
 The command is transmitted to the HUB via Ethernet / 4G or BT, the HUB transforms this command into CAN code to send it to the Powerail. The Powerail provide also input data to the HUB to feed the applications

Consumers and input



Command via Keypad :
 The command is directly send in CAN to the Powerail

Command via switches through IO box :
 The switches send a tension to the inputs of the IO box who transforms this into CAN command to send it to the Powerail



POWERAIL

How does it work ?
 1/6

On a **CAN network**, it is imperative to loop the network with a **120 Ohms resistance at each end of it**. This is so that the network returns to its initial state after the passage of a signal and that a new pulse can thus be emitted.

The Powerail is factory-fitted with a 120 Ohms resistance, which is why they do not appear on the Sailsense CAN network with Powerail(s). But it's important to have Powerail(s) (or 120 Ohms resistance) at the end of the backbone :



(In the case of an installation with more than 2 Powerails, they will activate their resistance automatically to have the correct impedance on the network)

The supply of the CAN1 network is provided by the Powerail as well, no need for a power cable. In addition, in the case of an **installation with two (or more) Powerails**, this offers **power supply redundancy**, which is an additional security.

POWERAIL

How does it work ?


2/6



Output activation :

Once the **action is performed** via the screen, keyboard or I/O box, the **Power-IC** (brain of the Powerail) **interprets** the CAN command and closes (or opens) the output following the action performed and **compared to the Powerail configuration**.

In doing so, it allows the battery to power the consumer (or not) after the output.



POWERRAIL

How does it work ?

3/6




Output disjunction :

When a **problem occurs** on a consumer or its electrical harness, the Powerail activates a **series of tests** on the output(s) which supply the consumer.

In a short time (5 seconds), the output is activated and deactivated more than 250,000 times with a cycle governed by the temperature of the output component (when the max T° is reached - 80°C - the tests stop) .

After this 5 secondes the output will go into **ERROR** mode.

On-screen display



Power supply

Powerail

Shortcut

Consumers default

To **clear the error**, you must **turn the consumer OFF** and then back **ON** on the screen (or keypad).


POWERAIL

How does it work ?

4/6



Dimming functionality :



POWERRAIL

How does it work ?

5/6




Leak control functionality :

The powerail **checks** whether there are any **leaks (positive and/or negative) between the service battery and the hull** using a shunt (current measuring device) integrated into the “H” input.

Once the **“H” input is connected to the boat’s ground**, the Powerail briefly **presents** its main power supply **“+” then “-”** (therefore the service battery) **every 10 seconds** (and when an output is activated) at the **shunt “H”**.

If the **values** (voltage and current) reported by the shunt are **equal to zero**, everything is **good**. On the other hand, **if one of the values is greater than 0**, a **leak is present**. The **galvanic isolation problems are vast** and the Powerail can very well detect the leak from the neighboring boat at the pontoon for example. The **safest way** to control a leak is to **remove the boat from the water** and carry out control measures.



POWERAIL

How does it work ?

6/6



POWERRAIL

Installation

1- The Powerail must be installed inside the boat.


To minimize installation time and limit the need to run additional cables, the Powerail should be placed as close as possible to the following:

- A 12V (12V Battery) or 24V (24V Battery) DC power source
- If possible in the “middle” all of the consumers you want to control to avoid excessively long wires

2- Screw the Powerail horizontally or vertically to the boat, with its front plate easily accessible, leaving enough space to access the device's terminals later.

We recommend installing the Powerail

- At least 1 meter above the level of the water
- At a distance of at least 0.5 m from others metal objects or water or fuel tanks




POWERAIL

Connection



Main informations



The polarity order of the outputs changes:


- Main terminal + → 1st wire +
- Main terminal - → 1st wire -

POWERRAIL


Connection overview



Connection to the Powerail :




The only way to connect the CAN network to the Powerail is to use a CAN cable stripped at one end to be able to connect the wires into the terminals :



- Black wire = Négative
- Blue wire = CAN Low
- Grey wire = Cable shield
- White wire = CAN High
- Red wire = Positive


POWERRAIL

CAN connection 1/2




Compliance with installation rules:

Avoid water-related problems :




Avoid interference :



Good practices

- 1- All cables are labelled 30cm from the connection point
- 2- Provide some length to be able to easily disconnect the devices in case of replacement
- 3- Make loops in damp places (drip loops)
- 4- Attach the cables every 45cm




POWERRAIL

CAN connection 2/2

CAN




Output wires connection



POWERRAIL

Heat dissipation

To improve **heat dissipation** of the Powerail, remember to allocate the most energy-intensive consumables close to the main Powerail supply terminals :



GOOD TO KNOW

- 1- You can use only the + or - of an output to control a consumer. For example: Victron converter control need a + to turn ON
- 2- Two outputs can be used in parallel to supply one consumer




Output wires identification

Sailsense provide you with tips to name your wires :

Example Powerail - output 1 :

PS01A - P (Powerail) / S (output) / 01 (N°output) / A (+)

PS01B - P (Powerail) / S (output) / 01 (N°output) / B (-)



POWERRAIL

Output connection

In case you install **multiple Powerail** :

Powerail #01 :

P1S01A - P1 (Powerail #01) / S (output) / 01 (N°output) / A (+)

P1S01B - P1 (Powerail #01) / S (output) / 01 (N°output) / B (-)

Powerail #02 :


P2S01A

P2S01B

When an output supply multiple consumers, the best way to name the wires is to keep the root (P1S07) and change the pairs after the root (A/B - C/D - E/F - ...), for example :



This way of naming allows to be more efficient in troubleshooting, in this case we know that the source is output 7 of Powerail #01



Input wires identification

Sailsense provide you with tips to name your wires :

Example Powerail - input 1 :

PE01A - P (Powerail) / E (input) / 01 (N°input) / A (+)

PE01B - P (Powerail) / E (input) / 01 (N°input) / B (-)

In case you install **multiple Powerail** :

Powerail #01 :

P1E01A - P1 (Powerail #01) / E (input) / 01 (N°input) / A (+)

P1E01B - P1 (Powerail #01) / E (input) / 01 (N°input) / B (-)

Powerail #02 :

P2E01A


P2E01B



This way of naming allows to be more efficient in troubleshooting.


In the following pages we explain how to connect :

- Analog gauge
- Ultrasound gauge
- Voltmeters
- Lin for IBS battery
- Bilge pump : auto and force mode + alert signal




POWERAIL

Input connection 1/5




Analog gauge connection




The only way to connect analog gauge to the Powerail is to **implement an 180 Ohms resistance (or 1200 Ohms to reduce consumption)** between the gauge power supply “PS” (who is a stable power supply, “independent” of battery voltage) and the positive wire of the gauge. Example input 1 below :

*In case you have **multiple gauges** in the inputs of one Powerail, the best and cleanest way to connect it all is to pass through a **junction box**.*



POWERRAIL

Input connection 2/5



The Powerail reads the difference between the implemented resistance and the gauge's variable resistance. It sends these readings to the HUB which, through the tank equation (calculate during the study), displays the correct value on the screen.




Ultrasound gauge connection

The ultrasound gauge are simpler to connect but may represent a cost for the yard.
 To connect it to the Powerail, follow the instruction below (example input 1):

Tips to name your wires:

- PE01A -> + sensor supply
- PE01B -> - probe power supply
- PE01C -> signal (generally between 0V and 5V, gauge's specifications to check)


*In case you have **multiple gauges** in the inputs of one Powerail, the best and cleanest way to connect it all is to pass through a **junction box**.*




The Powerail reads the signals, sends these readings to the HUB which, through the tank equation (calculate during the study), displays the correct value on the screen.

Voltmeters connection

Number of voltmeter per Powerail : 3
 Reading range : -30VDC // +30VDC



IMPORTANT : Don't forget to add a 3A fuse to the (+) voltmeter wire at the battery outlet. To be sure of the reading, Sailsense advises you to pass wires + and - between the battery you want to monitor and the voltmeter of the Powerail.
 Example voltmeter 1 :



Sailsense provide you with tips to name your wires :

Example Powerail - voltmeter 1 :
 PV01A - P (Powerail) / V (voltmeter) / 01 (N°voltmeter) / A (+)
 PV01B - P (Powerail) / V (voltmeter) / 01 (N°voltmeter) / B (-)

In case you install **multiple Powerail** :

Powerail #01 :
 P1V01A - P1 (Powerail #01) / V (voltmeter) / 01 (N°voltmeter) / A (+)
 P1V01B - P1 (Powerail #01) / V (voltmeter) / 01 (N°voltmeter) / B (-)


Powerail #02 :
 P2V01A
 P2V01B



This way of naming allows to be more efficient in troubleshooting.

POWERAIL

Input connection 4/5





LIN connection :

Instead of voltmeter you can use **IBS** to monitor your batteries.

- Maximum number of IBS per Powerail : **1**
- Tension : 12VDC / 24VDC
- Maximum current -> follow the specifications of your supplier


IBS provide **more informations** : current consumption and production, temperature, state of charge, state of health.

To connect it to the Powerail, follow the instruction below :




POWERAIL

Input connection 5/5



Bilge pump : AUTO and FORCED mode + alert signal connection



Bilge pump being a security component of your boat, we advise you to power supply them in two different ways :

- **AUTO mode**, power supply directly by the service battery (+ and -) and protected by a fuse.
- **FORCED mode**, power supply by the Powerail with only a +.

To be alerted when a bilge pump run in AUTO mode, connect a wire between the float (after contact) and an input on the Powerail.

The Powerail will receive the voltage when the contact closes and after several seconds of operation will send an alert message to the HUB which will display it on the screen and inform you remotely by sending an SMS/email.

On the next page you will find a scheme of a bilge pump + a float connected to the battery and the Powerail.


Some bilge pumps do not need a float because it is integrated into the pump. In this case you can take the input alert directly from the FORCED mode wire because most of the time the voltage returns via this wire when AUTO mode is running (check your pump specifications).

POWERAIL

Bilge pump connection
1/2



Bilge pump : AUTO and FORCED mode + alert signal connection



POWERAIL

Bilge pump connection
2/2



POWERAIL

Optional features




As an option you can have digital control panel for your Powerail

The idea is to provide a **backup switching mode**. It consists of replacing the classic front plate with the digital one which is **equipped with switches on each output hidden behind the designations**.

To do this, the panel is connected **directly to the Power-IC** (brains of the Powerail), meaning that **commands do not go through CAN1**.

Working in this way allows us to **avoid CAN problems** that can arise: unplugged wire / cut cable / broken connector / etc. And it **provides security to the user(s)**.

When an output is activated, the LED behind the number turns green (example output 12), when there is a problem with the output, the network or the consumer it turns red (example output 20) :



POWERAIL


Optional feature

Digital control panel



BLINK KEYPAD

Optional feature
Presentation



BLINK KEYPAD

Specification



Link Blink marine

[products](#)

Water and dust resistant

Yes

Dimensions

Varies depending on product choice - from 2 to 15 switches

Supply

8-32VDC

Power drain

<50mA

Protocol

(Blink offer the choice between 3 protocols : RS385 / CANopen / J1939)



J1939

Icon

Blink marine offers a large choice



BLINK KEYPAD


How does it work ?

CAN



Output activation :


Once the action is performed via the keyboard, the Power-IC (brain of the Powerail) interprets the CAN command and closes (or opens) the output following the action performed and compared to the Powerail configuration. In doing so, it allows the battery to power the consumer (or not) after the output.



BLINK KEYPAD

Installation


CAN



BLINK KEYPAD

Connection

GREEN= TxRx-(RS485)
 BLACK=GROUND
 RED=POWER
 ORANGE= TxRx+(RS485)
 WHITE=CAN HIGH
 BLUE=CAN LOW



All Blink keypads are supplied as standard with an Amphenol AT04-4P socket fitted. The mating plug is NOT supplied (but is available as an optional accessory) : [Kit-amphenol](#)

CAN



To connect the keypad to the Sailsense CAN1 you must create this cable :


BLINK KEYPAD

SAILSENSE CAN1




1	CAN-L
2	CAN-H
3	V-
4	V+

CAN-BLINK



M12 male

Shield	1
V+	2
V-	3
CAN-H	4
CAN-L	5



Deutsch connector DT 4 ways female

BLINK KEYPAD

Led behaviour

CAN



Color code :

- Blue : Off
- Green : On
- Red : error

BLINK IO BOX

Optional feature
Presentation



Water and dust resistant

Yes

Dimensions

130x42x63 mm

Supply voltage

8 to 32 VDC

Power drain

< 30mA

Protocol

J1939

(Blink offer the choice between 3 protocols : RS485 / CANopen / J1939) 

Contact switch input

8

The input voltage corresponds to the battery voltage

IO box

Specification




Output activation :

Once the action is performed via an onboard switch, a tension is sent to an input of the IO box. The IO box then transforms this signal to a CAN command.

The Power-IC (brain of the Powerail) interprets the CAN command and closes (or opens) the output following the action performed and compared to the Powerail configuration.

In doing so, it allows the battery to power the consumer (or not) after the output.




IO box

How does it work ?



Screw the IO box horizontally or vertically to the boat, with the connector easily accessible for the aftersale :



IO box

Installation

CAN




All IO box are supplied as standard without Cinch connector but is available as an optional accessory :

30-ways Cinch connector for IO box
[Kbconn30](#)



Sailsense **can provide** this connector with the **right length and configuration** needed for your boat. Just send us the specifications and we'll do the work and test :



IO box

Conection



JOTFORM

Configuration tool presentation



MacBook Pro

Sailsense provide tools to configure your BOAT :

We create online forms for you using the JotForm tool, to help you configure your installation. Depending on your needs, you can use :



- JotForm for **HUB only**.
- JotForm for **HUB + Powerail + Blink keypad / IO box** with full customization.
- Jotform for **shipyard with mass production**, allows you to choose the boat model and the options you want to activate.
- Jotform **on request for large projects**.

The advantage of this tool is that it can update a configuration remotely so no need to be on board ;)



BOAT Configuration




BOAT

Configuration example 1/6
Jotform for shipyard with mass production, allows you to choose the boat model and the options you want to activate.



1. The Sailsense team sends an **invitation email** to join the Jotform platform :



2. Click on **“view form”**

3. The internet link is activated and **you arrive at the form** (remember to save the link as favorites on your browser) ->


BOAT

Configuration example 2/6

Jotform for shipyard with mass production, allows you to choose the boat model and the options you want to activate.

1. Choose the boat model from the list

2. Enter the Boat ID



The screenshot shows the SAILSENSE configuration interface. It includes a language dropdown set to 'Français'. The 'Boat model' field is a dropdown menu with '44 open' selected, and a dropdown list is open showing options: 'Please Select', '44 open', and '40 open'. The 'Boat ID' field contains '018'. The 'HUB ID' field contains 'H01080EVK'. There is a 'Scan Barcode' button and a 'Suivant' button. Numbered callouts 1 through 5 highlight the dropdown menu, the Boat ID field, the HUB ID field, the Scan Barcode button, and the Suivant button respectively.

3. Enter the **HUB ID** present on the QR code label or 4. scan it with your phone / tablet to avoid errors :



5. Click next ->



1. Select the options according to the boat's configuration


SAILSENSE

44 open options :

- Submarine lighting
- Electronic
- Retractable lamp
- Fans
- Under bridge deck lighting
- HIFI
- Saloon indirect lighting
- Courtesy lighting
- Spreader light
- Sea water pump
- Deck wash fresh water pump
- Deck wash sea water pump
- Oven - gas plate inverter

Lithium batteries installed NO

Retour
Suivant

2. Click next ->

BOAT

Configuration example 3/6
Jotform for shipyard with mass production, allows you to choose the boat model and the options you want to activate.



BOAT

Configuration example 4/6

Jotform for shipyard with mass production, allows you to choose the boat model and the options you want to activate.



1. Enter your email address

 SAILSENSE

Email * 1

exemple@exemple.com

Please verify that you are human *

protection par reCAPTCHA Confidentialité - Conditions 

Retour

2

2. Click submit ->

BOAT

Configuration exemple 5/6

Jotform for shipyard with mass production, allows you to choose the boat model and the options you want to activate.



1. If asked, answer the **CAPTCHA**

1 Je ne suis pas un robot 
reCAPTCHA
Confidentialité - Conditions

2 **Submit Form**


2. Click **submit form** ->



Thank You!
Your submission has been received.

Créez maintenant votre propre Jotform - C'est gratuit ! [Créez votre propre Jotform](#)

A **confirmation email** will be sent to you and the Sailsense team will be informed that a new configuration has been uploaded by you for this boat :



The new configuration is sent to the **Sailsense Cloud**. The HUB (provided it is connected to 4G) will download this new configuration. The old one will be stored in archives in the Cloud.

BOAT

Configuration example 6/6
Jotform for shipyard with mass production, allows you to choose the boat model and the options you want to activate.



POWERAIL

LED color





For any question or feedback, please contact Sailsense via :

Mail : support@sailsense.io

WhatsApp : +44 7418 310794

Sailsense knowledge base : <https://help.sailsense.io/en>



 **SAILENSE**

The information contained in these documents is confidential, privileged and only for the information of the intended recipient and may not be used, published or redistributed without the prior written consent of Sailsense Analytics SA.