

# Diagnosis

Powerail synchronization fault  
For Nautitech boats




# Synchronization


## Diagnosis 1/2

Few commands need **synchronization** between the **Port and Starboard Powerail** :

- **Navigation Lights** (command via B&G screen and Blink keypad): Port output 04 + Starboard output 06



- **Secret light foredeck** (command via B&G screen) : Port output 03 + Starboard output 03
- **Indoor / outdoor Lights** (command via Blink keypad) : Port outputs 05,06,08,09,10,11,18 + Starboard outputs 05,07,08,09



# Synchronization

## Diagnosis 2/2

It happens that a desynchronization appears between Portside and starboard, meaning that when Portside is ON, Starboard is OFF

For the **navigation light** a visual check of the lights can confirm the desynchronization and/or the Blink keypad stay green when you turn OFF the Navigation lights (meaning one side off the boat is still ON)


For **secret light**, only a visual check of the lights can confirm the desynchronization.

For the **indoor / outdoor Lights** you will see the desynchronization directly on the Sailsense App :

-> When you press the “Lights Blink bouton” the “Port lights” and “Nacelle lights” cards turn ON but the “STBD lights” card remain OFF

-> You press again the Blink bouton, the “Port lights” and “Nacelle lights” cards turn OFF and the “STBD lights” card turn ON

To manually synchronize the Powerail, follow the instructions of the next page ->





# Synchronization

Handling 1/3

For example, you have a desynchronization with indoor/outdoor lights : “Port lights” and “Nacelle lights” cards are ON and “STBD lights” OFF

- **Step 1 : disconnect the CAN cable of the Port Powerail from the CAN network near the Sailsense HUB**



# Synchronization


Handling 2/3

- Step 2 : Turn ON “STBD lights” by pressing the Blink keypad bouton




Now all the cards (Port lights / Nacelle lights / STBD Lights) are ON on the B&G screen

- Step 3 : Reconnect Port Powerail to the CAN bus




- Step 4 : Control the synchronisation Portside/Starboard by pressing the Blink Keypad



# Synchronization

Handling 3/3

For **Navigation Lights** and **secret light** the **steps are the same**, only the **way to control change** : Navigation - App + Blink keypad / Secret lights - App





For any question or feedback, please contact Sailsense via :

Mail : [support@sailsense.io](mailto:support@sailsense.io)

WhatsApp : +44 7418 310794

Sailsense knowledge base : <https://help.sailsense.io/en>



 **SAILSENSE**

The information contained in these documents is confidential, privileged and only for the information of the intended recipient and may not be used, published or redistributed without the prior written consent of Sailsense Analytics SA.